


## Spill Prevention and Containment

- ✓ Provide impermeable ‘Secondary Containment’ structures for aboveground chemical and fuel storage tanks.
- ✓ Ensure that underground tanks are meeting standards set by Ohio’s Bureau of Underground Storage Tank Regulations. In a Source Water Protection Area, underground tanks must be double-walled and **meet leak detection and prevention requirements**. Noncomplying tanks must be removed.
- ✓ Provide berms around chemical or fuel loading and unloading areas to help contain any leaks or spills.
- ✓ Provide storage areas for chemical drums that are roofed, set on an impermeable concrete floor without floor drains, and securely locked.
- ✓ Install systems to prevent overfilling of tanks, such as feed cut-off systems and by-pass systems to stand-by tanks.

## Contingency Planning

- ✓ Have a contingency plan for accidents (fire, flood, explosion, collision, etc.) that may result in chemical spills.
- ✓ Notify Ohio EPA's Spill Hotline at (800) 282-9378 when spills occur.
- ✓ **Keep contact information for nearby public water systems and notify them when spills occur.**

## Your Town



## Plumbing/Septic Systems

- ✓ Have your septic tank inspected annually and cleaned every five years.
- ✗ Don't pour chemicals down ANY drain leading to a septic tank.

## Employee Training

- ✓ Store and transport chemicals properly.
- ✓ Respond to spills quickly and correctly.
- ✓ Monitor chemical inventory.

## Technology and Process Training

- ✓ Redesign or reformulate end products to be less hazardous.
- ✓ Change process parameters, equipment, or the process itself to reduce the amount of waste generated.
- ✓ Reduce raw materials used in processes.
- ✓ Contact Ohio EPA's Office of Pollution Prevention (614) 644-3469 for FREE Pollution Prevention Technical Assistance.

For more information about Source Water Protection scan the QR code — or call us at (614) 644-2752

